www.brunner-innovation.swiss



Control leading system Active profile: Default Profile Bevator(En) Bevator Tim(Dia) Aleron Tim(Dia) Throttle 1(Dia) Throttle 2(Dia)	Rudder(Dis) Collective(Dis) Rudder Trim(Dis) Throttle 3(Dis) Throttle 4(Dis)	Profile manager Nosewheel(Dis) Brake left(Dis) Brake right(Dis) Speedbrake(Dis)				
Hardware	off (On) Switched on (En) Operation enabled (Ho Simulation	m) Homing entor (Pt) General Entor : 127.0.0.1 60 updates/s				
Disconnect Int Stop	125 updates/s (2) Disconnect Si	atus: Toconnected to X-Plane (Plugin v 10.6.0.4)				
	CLS profile manager Profiles:	Configuration of selected profile;			-	
Airspeed: 0 Knots	♣ Add X Remore IN Remare	Plath Rel Paston 34 Paston 34 Paston 34 Paston 34 Paston 34 Paston 34 Paston 310 Paston 26 Paston 76 Paston 710 Paston 100 <	vibrations Ground vibrations	Tubulences inabled % Force min 1 0 % Force max 40 0 % Senstivity 30 0 Ramp 5 0	Use custom Stall settings Stall speed 1 Angle of Attack (degrees) 1,00	•
	Legend (L) Profile is linked to current aircraft. (A) If multiple profiles link to the same aircraft, this will be the preferred link.		e e			
and the second						

CLS2SIM software.

Your choice for easy integration of BRUNNER CLS to any Simulation SW environment.

BRUNNER CLS2Sim software is a proven solution for connecting and integrating our Active Force Feedback flight simulator devices to any simulator software environment.


CLS2Sim allows extensive configuration of all our devices. Set up force by deflection and force increase with speed, control trim with and without our electric trim wheels and use the autopilot of the simulation to drive yoke, rudder or other axes.

Enable a wide range of effects like engine or runway vibrations, or stick shaker etc. for up to 20 axes connected to the CAN network. Prepar3D[®], M-FSX and X-Plane are directly supported. Any third party flight simulation solution connects via a clean TCP/IP or UDP remote interface protocol which simplifies handling and reduces implementing effort to a minimum.

Read positions, buttons, forces and status information and control trim, autopilot, or force profiles for each connected axis using simple commands.

FACTSHEET CLS2SIM SOFTWARE.

www.brunner-innovation.swiss





BRUNNE dedication + innovat

CLS2SIM software.

Features.

- Connect to CLS via Ethernet TCP/IP, USB
- Plug->Configure->Play Support for motorized axes: Yoke, Rudder Pedal, Cyclic, Collective, Trim Wheel, Throttle, Brakes.
- Support for any custom motorized axis over external control interface (Nose wheel, Speed brakes, etc.)
- Force/deflection curve scaling with speed
- Axis linearity, dead zones and artificial play
- Trim and Autopilot
- Motor and runway vibrations
- Stick shaker

Specification

Comunication-Interfaces Ethernet, CAN, USB, RS232

Minimium Requirements Dual Core, 2.0 GHz or faster 2 GB of RAM

- Compatible with PMDG 737-800 NGX, others on request
- Supports Multi Crew-Cockpit (MCC)
- UDP or TCP/IP Interface for external control
- Operating System: Win XP/Vista/7/8/10
- Linux & Mac Plugin for X-Plane
- Swiss Made

Not share from their box here by the fore has factor to be the fore the factor to be the factor	ch axis force settings for pr	onie "Derauit Profile"					
$\begin{tabular}{ c c c c } \hline \begin{tabular}{ c c c c c c c c c c c c c c c c c c c$							
$\begin{array}{c} \hline \bell \\ \hline \bell \ \bell \\ \hline \bell \\ \hline \bell \ \ \ \bell \\ \hline \bell \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	ise static Force Factor						
Carry Seed 0 Image: 1 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	0.0 🗘						
Constituted of the speed of the	lee dynamic Force Factor						
Ma Speed (20) Ma Speed (20) Ma Force log Fector) (2) Mae Force (and Fector) (9)	Factor: 20	forcevalue at =	Factor + forcevalue				
	Add Remove Move	Clear					
	4in Speed 0	Max Speed 200	Min Force (big Factor) 20	Max Force (small Factor) [1	0		
		Max Speed 200	Min Force (big Factor)	Max Force (small Factor)	0		/
		Max Speed 200	Min Force (big Fector) 20	Max Force (small Factor)	0	_	/
		Max Speed 200	Mn Ferce by Fetal 20	Max Force (small Factor) []		_	/
		Max Speed 200	Mn Force big Facter) [20	Max Force (mail Factor)		_	/
Max Speed Max Sp		Max Sceed 200	Mn Ferce (rg Facter) (20	Mex Force land Flector [

General Buttons Analog Inputs Axis Range settings Axis force settings Autopilot Hydraulics Shutdown Trim Yoke Display





